



# 1. SUBSTRATE PREPARATION

The existing floor tiles must be sound and well secured to the substrate. Any loose, broken or drummy tiles should be removed and the void filled with:



### **ARDEX A45**

Rapid Hardening & Drying Repair Mortar for internal repairs and dormant cracks

The cleaned surface is to be mechanically prepared to provide a clean 'keyed' surface. Mechanical preparation is advised for the floor levelling products but is not required if Feather Finish is to be used.

Prime ceramic tile/terrazzo with:



#### **ARDEX P9**

Single Part Primer for Smooth and Dense Surfaces

Make sure that excess primer does not accumulate in the tile grout lines.

## 2. INSTALL SMOOTHING/SELF LEVELLING



### **ARDEX FINE FINISH**

Smoothing for thicknesses 1.5 - 3mm

### **ARDEX FEATHER FINISH**

Rapid drying smoothing for thicknesses 1.5 - 3mm

### ARDEX K 120

Economic levelling for thicknesses 2.5 - 12mm

### **ARDEX K220**

Low odour levelling for thicknesses 2 - 20mm

## ARDEX K12 NEW

Super smooth levelling for thicknesses 1.5 - 35mm

### **ARDEX K10 REACTIV8**

Long open time levelling for thicknesses 1.5 - 15mm

### ARDEX K15

Fibre reinforced levelling for thicknesses  $1.5\mbox{ -}$  any depth

### **ARDEX K55**

Rapid drying levelling for thicknesses 1.5mm - any depth

### **ARDEX ARDITEX NA**

Flexible levelling for thicknesses 1.5

# 3. ADHESIVE FIX VINYL



### ARDEX AF 142

Fast grab vinyl adhesive

## ARDEX AF 180 MS

Heavy duty adhesive for areas with direct sunlight and moisture

Refer to the most current product datasheet and/or technical bulletin at www.ardexaustralia.com for installation instruction